

VIVAX

Dishwasher DW-601472C S



VIVAX DW-601472C S is a quiet (47 dB) built-in dishwasher for 14 place settings, with 7 programs (Auto, ECO, Night), a quick wash function, and additional drying. Ideal for large households with energy savings.

Description

VIVAX dishwasher DW-601472C S is ideal for large households.

Type of dishwasher

Freestanding

Power supply

220-240 V / 50 Hz, 1760-2100 W

Capacity (place settings)

14

Energy efficiency

E

Maximum noise level

47 dB

Water consumption per washing cycle

11 L /cycle

Start delay

3 - 6 - 9 - 12 h

Washing programs (6 programs)

Intensive, Universal, ECO, 90 min, Glass, Quick wash

Additional functions

Half load (upper/lower basket), Timer with start delay (1-24h), Adjustable water consumption, Extra drying, Child lock

Control panel (8 buttons)

On/Off, Program selection, Half load, Extra drying, Start delay, Pause/Reset, Child lock

Baskets (2 baskets)

Upper and lower basket with foldable racks; Foldable cup holder; Cutlery basket; Adjustable upper basket height

Accessories

Inlet hose, outlet hose, energy label, inlet hose length / outlet hose length: 1400 mm / 1500 mm / 1500 mm

Package dimensions / Appliance dimensions (W x H x D)

64,5 x 89,0 x 64,5 cm / 59,8 x 84,5 x 60,0 cm

Gross / Net weight


46,5 kg / 42,0 kg

EAN Code


3856005199686

SAP Code

0001398805



Innovative technology, a wide range of programs, and special functions ensure thorough cleaning of every dish.



This dishwasher provides space for 14 place settings in two large baskets with foldable racks and an additional third shallow sliding cutlery tray, located on top of the upper basket.

VIVAX

Dishwasher DW-601472C S



14
SETS



2
BASKETS



QUICK
WASH



QUIET
49 dB



7
PROGRAMS

VIVAX DW-601472C S is a quiet (47 dB) built-in dishwasher for 14 place settings, with 7 programs (Auto, ECO, Night), a quick wash function, and additional drying. Ideal for large households with energy savings.



The elegant black control panel features illuminated controls and LED indicators for all selected functions, washing phases, as well as salt and rinse aid shortage warnings.



With the intensive wash program, even the most stubborn stains are removed, while the half-load option allows you to efficiently wash a smaller amount of dishes, saving both water and energy.

